

# JACDAC HEADMOUSE

A head mouse concept based on Jacdac microcontrollers ecosystem.

**Version 1.0**

<https://github.com/milador/Jacdac-HeadMouse>


## Contents

Components List .....	1
Software .....	3
JavaScript Demo Code .....	3
Hardware Assembly .....	6
Enclosure design .....	6
Assembly .....	7

## Components List

1. MICRO:BIT V2 x 1
2. [MICRO:BIT JACDAPTOR](#) x 1
3. [JACDAC ACCELEROMETER MODULE](#) x 1
4. JACDAC CABLE x 2
5. [LITHIUM-ION POLYMER BATTERY- 3.7V 1200MAH](#) x 1
6. M3 HEX NUT x 2

7. M3-8MM SCREW x 2
8. M2 HEX NUT x 6
9. M2-6MM SCREW x 4
10. M2-12MM SCREW x 2
11. [AMAZON BASICS HEAD STRAP CAMERA MOUNT FOR GOPRO](#) x 1
12. [GOPRO MOUNT TO 1/4-INCH 20 CAMERA ADAPTER](#) x 1
13. 1/4-INCH 20 TEE NUT x 1
14. (OPTIONAL) [JACDAC ACCESS SWITCH OUTPUT MODULE](#) x 1



- Item 14 is optional, and it's only required if you would like to control an access switch instead of cursor.

## Software

The demo code written using MakeCode blocks is available and it can be accessed through following link.

[https://makecode.microbit.org/\\_heFTpmWCwD0o](https://makecode.microbit.org/_heFTpmWCwD0o)

## JavaScript Demo Code

You can also copy and paste the following code to MakeCode JavaScript code editor field:

```
input.onButtonPressed(Button.A, function () {  
  initialize()  
})  
function initialize () {  
  counter = 3  
  while (counter >= 0) {  
    basic.showNumber(counter)  
    basic.pause(1000)  
    counter += -1  
  }  
  basic.pause(200)  
  soundExpression.hello.play()  
  x_init = modules.accelerometer1.x()  
  y_init = modules.accelerometer1.z()  
}  
let y_val = 0  
let x_val = 0  
let counter = 0
```

```

let y_init = 0
let x_init = 0
let count = 0
let x_threshold = 0.05
let y_up_threshold = 0.22
let y_down_threshold = 0.05
x_init = -0.2
y_init = 0.1
initialize()
basic.forever(function () {
  led.stopAnimation()
  if (modules.accelerometer1.x() < x_init - x_threshold) {
    x_val = 1
  } else if (modules.accelerometer1.x() > x_init + x_threshold) {
    x_val = -1
  } else {
    x_val = 0
  }
  if (modules.accelerometer1.z() < y_init - y_up_threshold) {
    y_val = 1
  } else if (modules.accelerometer1.z() > y_init + y_down_threshold) {
    y_val = -1
  } else {
    y_val = 0
  }
  if (x_val == 0 && y_val == 0) {
    basic.showLeds(`
      .....
      .....
      ..#..
      .....
    `)
  }
})

```

```

.....

`)

modules.hidKeyboard1.clear()
} else if (x_val == 0 && y_val != 0) {
    if (y_val > 0) {
        basic.showArrow(ArrowNames.North)

        modules.hidKeyboard1.key(jacdac.HidKeyboardAction.Press, jacdac.HidKeyboardModifiers.None,
jacdac.HidKeyboardKey.UpArrow)

    } else {
        basic.showArrow(ArrowNames.South)

        modules.hidKeyboard1.key(jacdac.HidKeyboardAction.Press, jacdac.HidKeyboardModifiers.None,
jacdac.HidKeyboardKey.DownArrow)

    }
} else if (x_val != 0 && y_val == 0) {
    if (x_val > 0) {
        basic.showArrow(ArrowNames.East)

        modules.hidKeyboard1.key(jacdac.HidKeyboardAction.Press, jacdac.HidKeyboardModifiers.None,
jacdac.HidKeyboardKey.LeftArrow)

    } else {
        basic.showArrow(ArrowNames.West)

        modules.hidKeyboard1.key(jacdac.HidKeyboardAction.Press, jacdac.HidKeyboardModifiers.None,
jacdac.HidKeyboardKey.RightArrow)

    }
} else if (x_val != 0 && y_val != 0) {
    if (x_val > 0 && y_val > 0) {
        basic.showArrow(ArrowNames.NorthEast)
    } else if (x_val < 0 && y_val > 0) {
        basic.showArrow(ArrowNames.NorthWest)
    } else if (x_val < 0 && y_val < 0) {
        basic.showArrow(ArrowNames.SouthWest)
    } else if (x_val < 0 && y_val > 0) {
        basic.showArrow(ArrowNames.SouthEast)
    }
}

```

```
} else {  
  
}  
} else {  
}  
})
```

## Hardware Assembly

### Enclosure design

The enclosure/housing files in STL format can be downloaded from GitHub repository under Hardware directory.

<https://github.com/milador/Jacdac-HeadMouse/tree/main/Hardware/Enclosure/STL>

Please print the following STL files:

- Jacdac-HeadMouse-Top.stl **x 1**
- Jacdac-HeadMouse-Bottom.stl **x 1**
- Jacdac-HeadMouse-Mounting.stl **x 1**

## Assembly



**Step 1: Insert the 1/4-inch-20 Tee Nut into the mounting enclosure piece and press it inward using a soldering iron.**






**Step 2-a: Identify the mounting screw holes of bottom enclosure piece and insert the mounting piece over.**




**Step 2-b: Identify two M3-8MM screws and two M3 hex nuts.**




**Step 2-c: Insert the M3 screws from outside the bottom enclosure.**




**Step 2-d: Insert the M3 hex nuts from bottom enclosure piece and tighten them to secure the mounting piece.**




**Step 3-a: Prepare components to secure accelerometer module in the bottom enclosure piece.**




**Step 3-b: Connect a Jacdac cable to one of the two Jacdac connectors in the accelerometer module.**



**Step 4-a: Insert all the four M2-6MM screws into the accelerometer module.**




**Step 4-b: Make sure all the four M2-6MM screws are inserted into the accelerometer module.**




**Step 4-c: Insert the accelerometer module into the bottom enclosure piece.**



**Step 4-d: Secure the accelerometer module by inserting four M2 hex nuts. The M2 hex nuts need to be tightened to prevent the module from moving.**



**Step 5-a: Insert the battery into the bottom enclosure piece.**




**Step 5-b: Connect the battery to the micro:bit board via JST connector.**







**Step 5-c: Insert the micro:bit board into the bottom enclosure piece.**



**Step 5-d: Insert two M2-12MM screws into the micro:bit screw holes of the bottom enclosure piece.**




**Step 5-e: Secure the micro:bit board by inserting four M2 hex nuts. The M2 hex nuts need to be tightened to prevent the board from moving.**



**Step 6: Connect the other end of the Jacdac cable into the middle connector of the Jacdaptor. The cable must be kept tucked away down in the bottom enclosure piece.**






**Step 7-a: Identify the top enclosure piece.**



**Step 7-b: Insert the top enclosure piece over the bottom enclosure and snap them together.**




**Step 8-a: Identify the 1/4-Inch 20 camera adapter.**



**Step 8-b: Insert and screw the 1/4-Inch 20 camera adapter into Jacdac Headmouse mounting piece.**



**Step 8-c: Identify the head strap camera mount.**



**Step 8-d: Connect the head strap camera mount to the Jacdac HeadMouse enclosure.**



**Step 9: The Jacdac HeadMouse is now fully assembled.**